

Programming

On or off-site programming for models with Auto-Dial capability.
(5500 AD, 5501 AD or any custom unit with "AD" listed in the model no.)

10-STEP AUTO-DIAL PROGRAMMING

- 1.) Connect the Asimitel Omnia Auto-Dial unit to a telephone line.
- 2.) From another telephone, place a call to the Auto-Dial unit.
- 3.) Answer the Auto-Dial unit (if programming off-site have someone answer for you and listen to your instructions).
- 4.) Enter the Manager PIN/Security Code (the default PIN is set to **845464**) if the PIN is entered correctly you will hear a confirmation tone or "double beep".
- 5.) Enter *4 (allows touch-tone dialing by the user, to block possible user dialing Enter *3. For pulse/rotary dialing Enter *6) *Note: It is not possible to program a * or # in pulse mode.*
- 6.) Enter *2 (allows for ultra-fast dialing, Enter a*1 to slow dialing).
- 7.) Enter the number you desire to be Auto-Dialed (if necessary, to include pauses, Enter a*8 for a one-second pause or Enter*7 for a four-second pause).
- 8.) When finished enter #0 to conclude your session. If programming was successful you will here a confirmation tone or a double beep.
- 9.) Hang up the Auto-Dial unit (if programming off-site instruct your helper to hang up and test the unit by lifting the handset to see if the correct number will auto-dial).
- 10.) Lift the handset of the Auto-Dial to test, the number programmed should speed-dial (if the unit does not dial or dials improperly repeat steps 1 through 10 before calling Asimitel technical support).

• Things to Remember

Dial 9

Some phone systems or service may require a dial 9 or even two 9's before accessing an outside line. To confirm check with your telephone system/PBX administrator or operators manual. If a nine is necessary remember to program it in the number string (Step 7).

Long Distance

If your desired number is going long distance remember to dial a 1 before the number

EXAMPLES

To Auto-Dial 911 in Touch-Tone mode: Complete up to Step 4, then Enter *4, *2, 911, #0

To Auto-Dial 911 in Pulse mode: Complete up to Step 4, then Enter *6, *2, 911, #0

To Dial 911 in Pulse mode followed by a Touch-Tone 3: Complete up to Step 4, then Enter *6, *2, 911, *6, 3, #0

For Programming Assistance Call: 613-545-0534 Tech Support is available from 9am to 5pm EST



10 Binnington Court
Kingston, Ontario.
K7M 8S2

CHANGING THE PIN/SECURITY CODE

- 1.) From another telephone, place a call to the Auto-Dial unit.
- 2.) Answer the Auto-Dial unit (if programming off-site have someone answer for you and listen to your instructions.)
- 3.) Enter 845464
- 4.) Listen for the two beeps, then enter your new code (must be 6 digits)
- 5.) Enter #9 and listen for two beeps

***If you DO NOT hear the two beeps on step 4 and step 5 hang up and start over.*

***Once the PIN is changed the phone cannot be re-programmed or modified without the new code. Please write down your new PIN and store in a secure place.*

TO DISABLE THE AUTO-DIAL FUNCTION

THIS FEATURE WILL WIPE THE DEFAULT PROGRAMMING AND ALLOW YOU TO USE THE PHONE AS A STANDARD NON-DIAL PHONE.

- 1.) From another telephone, place a call to the Auto-Dial unit.
- 2.) Answer the Auto-Dial unit (if programming off-site have someone answer for you and listen to your instructions.)
- 3.) Enter 845464 or your PIN
- 4.) Listen for the two beeps, then Enter #0